

# FarSync X.21 Interface

Document revision 1.1 (Fri Mar 05 08:14:24 GMT 2004)

This document applies to V2.8

## Table of Contents

[Table of Contents](#)

[General Information](#)

[Summary](#)

[Specifications](#)

[Related Documents](#)

[Additional Documents](#)

[Synchronous Interface Configuration](#)

[Description](#)

[Property Description](#)

[Example](#)

[Troubleshooting](#)

[Description](#)

[Synchronous Link Applications](#)

[MikroTik router to MikroTik router](#)

[MikroTik router to MikroTik router P2P using X.21 line](#)

[MikroTik router to Cisco router using X.21 line](#)

[MikroTik router to MikroTik router using Frame Relay](#)

## General Information

### Summary

The MikroTik RouterOS supports FarSync T-Series X.21 synchronous adapter hardware. These cards provide versatile high performance connectivity to the Internet or to corporate networks over leased lines.

### Specifications

Packages required: *synchronous*

License required: *level4*

Home menu level: */interface farsync*

Standards and Technologies: *X.21, Frame Relay, PPP*

Hardware usage: *Not significant*

### Related Documents

- [Package Management](#)
- [Device Driver List](#)
- [IP Addresses and ARP](#)
- [Log Management](#)

## Additional Documents

- <http://www.farsite.co.uk/>

## Synchronous Interface Configuration

Home menu level: */interface farsync*

### Description

You can change the interface name to a more descriptive one using the **set** command. To enable the interface, use the **enable** command.

### Property Description

**hdlc-keepalive** (*time*; default: **10s**) - Cisco HDLC keepalive period in seconds

**clock-rate** (*integer*; default: **64000**) - the speed of internal clock

**clock-source** (*external | internal*; default: **external**) - clock source

**disabled** (*yes | no*; default: **yes**) - shows whether the interface is disabled

**frame-relay-dce** (*yes | no*; default: **no**) - operate in Data Communications Equipment mode

**frame-relay-lmi-type** (*ansi | ccitt*; default: **ansi**) - Frame Relay Local Management Interface type

**line-protocol** (*cisco-hdlc | frame-relay | sync-ppp*; default: **sync-ppp**) - line protocol

**media-type** (*V24 | V35 | X21*; default: **V35**) - type of the media

**mtu** (*integer*; default: **1500**) - Maximum Transmit Unit

**name** (*name*; default: **farsyncN**) - assigned interface name

### Example

```
[admin@MikroTik] > interface print
Flags: X - disabled, D - dynamic, R - running
#   NAME           TYPE           MTU
0   R ether1        ether          1500
1   X farsync1       farsync        1500
2   X farsync2       farsync        1500
[admin@MikroTik] interface>
[admin@MikroTik] interface> enable 1
[admin@MikroTik] interface> enable farsync2
[admin@MikroTik] > interface print
Flags: X - disabled, D - dynamic, R - running
#   NAME           TYPE           MTU
0   R ether1        ether          1500
1   farsync1       farsync        1500
2   farsync2       farsync        1500
[admin@MikroTik] interface>farsync
[admin@MikroTik] interface farsync> print
Flags: X - disabled, R - running
0   name="farsync1" mtu=1500 line-protocol=sync-ppp media-type=V35
    clock-rate=64000 clock-source=external chdlc-keepalive=10s
    frame-relay-lmi-type=ansi frame-relay-dce=no

1   name="farsync2" mtu=1500 line-protocol=sync-ppp media-type=V35
    clock-rate=64000 clock-source=external chdlc-keepalive=10s
    frame-relay-lmi-type=ansi frame-relay-dce=no
```

```
[admin@MikroTik] interface farsync>
```

You can monitor the status of the synchronous interface:

```
[admin@MikroTik] interface farsync> monitor 0
  card-type: T2P FarSync T-Series
  state: running
  firmware-id: 2
  firmware-version: 0.7.0
  physical-media: V35
    cable: detected
    clock: not-detected
  input-signals: CTS
  output-signals: RTS DTR

[admin@MikroTik] interface farsync>
```

## Troubleshooting

### Description

- **The farsync interface does not show up under the interface list**  
Obtain the required license for synchronous feature
- **The synchronous link does not work**  
Check the cabling and the line between the modems. Read the modem manual

## Synchronous Link Applications

### MikroTik router to MikroTik router

Let us consider the following network setup with two MikroTik routers connected to a leased line with baseband modems:

The interface should be enabled according to the instructions given above. The **IP addresses** assigned to the synchronous interface should be as follows:

```
[admin@MikroTik] ip address> add address 1.1.1.1/32 interface farsync1 \
\... network 1.1.1.2 broadcast 255.255.255.255
[admin@MikroTik] ip address> print
Flags: X - disabled, I - invalid, D - dynamic
#   ADDRESS           NETWORK           BROADCAST         INTERFACE
0   10.0.0.254/24      10.0.0.254       10.0.0.255        ether2
1   192.168.0.254/24  192.168.0.254   192.168.0.255    ether1
2   1.1.1.1/32        1.1.1.2         255.255.255.255  farsync1
[admin@MikroTik] ip address> /ping 1.1.1.2
1.1.1.2 64 byte pong: ttl=255 time=31 ms
1.1.1.2 64 byte pong: ttl=255 time=26 ms
1.1.1.2 64 byte pong: ttl=255 time=26 ms
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max = 26/27.6/31 ms
[admin@MikroTik] ip address>
```

Note that for the point-to-point link the network mask is set to 32 bits, the argument **network** is set to the **IP address** of the other end, and the broadcast address is set to 255.255.255.255. The default route should be set to the gateway router 1.1.1.2:

```
[admin@MikroTik] ip route> add gateway 1.1.1.2
```

```
[admin@MikroTik] ip route> print
Flags: X - disabled, I - invalid, D - dynamic, J - rejected,
C - connect, S - static, R - rip, O - ospf, B - bgp
#   DST-ADDRESS      G GATEWAY      DISTANCE INTERFACE
0   S 0.0.0.0/0        r 1.1.1.2      1          farsync1
1   DC 10.0.0.0/24    r 10.0.0.254   1          ether2
2   DC 192.168.0.0/24 r 192.168.0.254 0          ether1
3   DC 1.1.1.2/32     r 0.0.0.0      0          farsync1

[admin@MikroTik] ip route>
```

The configuration of the MikroTik router at the other end is similar:

```
[admin@MikroTik] ip address> add address 1.1.1.2/32 interface fsync \
\... network 1.1.1.1 broadcast 255.255.255.255
[admin@MikroTik] ip address> print
Flags: X - disabled, I - invalid, D - dynamic
#   ADDRESS          NETWORK        BROADCAST      INTERFACE
0   10.1.1.12/24      10.1.1.12     10.1.1.255     Public
1   1.1.1.2/32       1.1.1.1       255.255.255.255 fsync

[admin@MikroTik] ip address> /ping 1.1.1.1
1.1.1.1 64 byte pong: ttl=255 time=31 ms
1.1.1.1 64 byte pong: ttl=255 time=26 ms
1.1.1.1 64 byte pong: ttl=255 time=26 ms
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max = 26/27.6/31 ms
[admin@MikroTik] ip address>
```

## MikroTik router to MikroTik router P2P using X.21 line

Consider the following example:

The default value of the property **clock-source** must be changed to **internal** for one of the cards. Both cards must have **media-type** property set to **X21**.

**IP address** configuration on both routers is as follows (by convention, the routers are named **hq** and **office** respectively):

```
[admin@hq] ip address> pri
Flags: X - disabled, I - invalid, D - dynamic
#   ADDRESS          NETWORK        BROADCAST      INTERFACE
0   192.168.0.1/24    192.168.0.0    192.168.0.255 ether1
1   1.1.1.1/32       1.1.1.2       1.1.1.2        farsync1

[admin@hq] ip address>

[admin@office] ip address>
Flags: X - disabled, I - invalid, D - dynamic
#   ADDRESS          NETWORK        BROADCAST      INTERFACE
0   10.0.0.112/24     10.0.0.0       10.0.0.255     ether1
1   1.1.1.2/32       1.1.1.1       1.1.1.1        farsync1

[admin@office] ip address>
```

## MikroTik router to Cisco router using X.21 line

Assume we have the following configuration:

The configuration of MT router is as follows:

```
[admin@MikroTik] interface farsync> set farsync1 line-protocol=cisco-hdlc \
\... media-type=X21 clock-source=internal
[admin@MikroTik] interface farsync> enable farsync1
[admin@MikroTik] interface farsync> print
Flags: X - disabled, R - running
```

```

0 R name="farsync1" mtu=1500 line-protocol=cisco-hdlc media-type=X21
  clock-rate=64000 clock-source=internal chdlc-keepalive=10s
  frame-relay-lmi-type=ansi frame-relay-dce=no

1 X name="farsync2" mtu=1500 line-protocol=sync-ppp media-type=V35
  clock-rate=64000 clock-source=external chdlc-keepalive=10s
  frame-relay-lmi-type=ansi frame-relay-dce=no

[admin@MikroTik] interface farsync>
[admin@MikroTik] interface farsync> /ip address add address=1.1.1.1/24 \
\... interface=farsync1

```

The essential part of the configuration of Cisco router is provided below:

```

interface Serial0
 ip address 1.1.1.2 255.255.255.0
 no ip route-cache
 no ip mroute-cache
 no fair-queue
 !
 ip classless
 ip route 0.0.0.0 0.0.0.0 1.1.1.1

```

## MikroTik router to MikroTik router using Frame Relay

Consider the following example:

The default value of the property **clock-source** must be changed to **internal** for one of the cards. This card also requires the property **frame-relay-dce** set to **yes**. Both cards must have **media-type** property set to **X21** and the **line-protocol** set to **frame-relay**.

Now we need to add **pvc** interfaces:

```

[admin@hq] interface pvc> add dlci=42 interface=farsync1
[admin@hq] interface pvc> print
Flags: X - disabled, R - running
# NAME MTU DLCI INTERFACE
0 X pvcl 1500 42 farsync1

[admin@hq] interface pvc>

```

Similar routine has to be done also on **office** router:

```

[admin@office] interface pvc> add dlci=42 interface=farsync1
[admin@office] interface pvc> print
Flags: X - disabled, R - running
# NAME MTU DLCI INTERFACE
0 X pvcl 1500 42 farsync1

[admin@office] interface pvc>

```

Finally we need to add **IP addresses** to **pvc** interfaces and enable them.

On the **hq** router:

```

[admin@hq] interface pvc> /ip addr add address 2.2.2.1/24 interface pvcl
[admin@hq] interface pvc> /ip addr print
Flags: X - disabled, I - invalid, D - dynamic
# ADDRESS NETWORK BROADCAST INTERFACE
0 10.0.0.112/24 10.0.0.0 10.0.0.255 ether1
1 192.168.0.1/24 192.168.0.0 192.168.0.255 ether2
2 2.2.2.1/24 2.2.2.0 2.2.2.255 pvcl

[admin@hq] interface pvc> enable 0
[admin@hq] interface pvc>

```

and on the **office** router:

```
[admin@office] interface pvc> /ip addr add address 2.2.2.2/24 interface pvc1
[admin@office] interface pvc> /ip addr print
Flags: X - disabled, I - invalid, D - dynamic
#   ADDRESS           NETWORK           BROADCAST        INTERFACE
0   10.0.0.112/24      10.0.0.0         10.0.0.255      ether1
1   2.2.2.2/24        2.2.2.0         2.2.2.255       pvc1

[admin@office] interface pvc> enable 0
[admin@office] interface pvc>
```

Now we can monitor the synchronous link status:

```
[admin@hq] interface pvc> /ping 2.2.2.2
2.2.2.2 64 byte ping: ttl=64 time=20 ms
2.2.2.2 64 byte ping: ttl=64 time=20 ms
2.2.2.2 64 byte ping: ttl=64 time=21 ms
2.2.2.2 64 byte ping: ttl=64 time=21 ms
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 20/20.5/21 ms
[admin@hq] interface pvc> /interface farsync monitor 0
    card-type: T2P FarSync T-Series
        state: running-normally
    firmware-id: 2
firmware-version: 1.0.1
    physical: X.21
        cable: detected
        clock: detected
    input-signals: CTS
    output-signals: RTS,DTR

[admin@hq] interface pvc>
```