



MikroTik RouterOS V2.6 Basic Setup Guide

MikroTik

Table of Contents

<u>MikroTik RouterOS V2.6 Basic Setup Guide</u>	1
<u>Introduction</u>	2
<u>Setting up MikroTik RouterOS</u>	4
<u>Downloading and Installing the MikroTik RouterOS</u>	4
1. <u>Download the basic installation archive file</u>	4
2. <u>Create the installation media</u>	4
3. <u>Install the MikroTik RouterOS software</u>	5
<u>Obtaining the Software License</u>	5
<u>Logging into the MikroTik Router</u>	7
<u>Adding Software Packages</u>	7
<u>Software Licensing Issues</u>	7
<u>Navigating the Terminal Console</u>	8
<u>Accessing the Router Remotely Using Web Browser and WinBox Console</u>	11
<u>Overview</u>	11
<u>Starting the Winbox Console</u>	11
<u>Overview of Common Functions</u>	14
<u>Troubleshooting for Winbox Console</u>	15
<u>Configuring Basic Functions</u>	16
<u>Working with Interfaces</u>	16
<u>Use of the 'setup' Command</u>	17
<u>Adding Addresses</u>	17
<u>Configuring the Default Route</u>	18
<u>Testing the Network Connectivity</u>	18
<u>Application Examples</u>	20
<u>Application Example with Masquerading</u>	20
<u>Application Example with Bandwidth Management</u>	20
<u>Application Example with NAT</u>	21

MikroTik RouterOS V2.6 Basic Setup Guide

[PDF version](#)

Introduction

Document revision 29–Nov–2002

This document applies to the MikroTik RouterOS V2.6

MikroTik RouterOS is independent Linux–based Operating System for PC–based routers and thinrouters. It does not require any additional components and has no software prerequisites. It is designed with easy–to–use yet powerful interface allowing network administrators to deploy network structures and functions, that would require long education elsewhere simply by following the Reference Manual (and even without it).

MikroTik RouterOS turns a standard PC computer into a network router. Just add standard network PC interfaces to expand the router capabilities.

- Remote control with easy real–time Windows application (WinBox)
- Telnet/console/serial console control
- Advanced bandwidth control
- Network firewall with packet–filtering, masquerading, network address translation, logging and connection monitoring
- DHCP support
- HotSpot technology
- Ethernet 10/100/1000Mb/s
- Wireless client and AP 2.4GHz 11 Mb/s
- V.35 synchronous 5Mb/s with frame–relay
- Asynch PPP/RADIUS (up to 32 ports) for modem pools
- Cyclades and LMC DS3 with E1/T1 support
- IP Telephony Gateway
- Built–in Web–proxy
- And much more

The Guide describes the basic steps of installing and configuring a dedicated PC router running MikroTik RouterOS. The following sections are included in this Guide:

- Setting up MikroTik RouterOS
 - ◆ Downloading and Installing the MikroTik RouterOS
 - ◇ 1. Download the basic installation archive file.
 - ◇ 2. Create the installation media
 - ◇ 3. Install the MikroTik RouterOS software.
 - ◆ Obtaining the Software License
 - ◆ Logging into the MikroTik Router
 - ◆ Adding Software Packages
 - ◆ Software Licensing Issues
- Navigating the Terminal Console
- Accessing the Router Remotely Using Web Browser and WinBox Console
 - ◆ Overview
 - ◆ Starting the Winbox Console
 - ◆ Overview of Common Functions
 - ◆ Troubleshooting for Winbox Console
- Configuring Basic Functions
 - ◆ Working with Interfaces
 - ◇ Use of the 'setup' Command
 - ◆ Adding Addresses
 - ◆ Configuring the Default Route
 - ◆ Testing the Network Connectivity
- Application Examples


Introduction

- ◆ Application Example with Masquerading
- ◆ Application Example with Bandwidth Management
- ◆ Application Example with NAT

Setting up MikroTik RouterOS

Downloading and Installing the MikroTik RouterOS

The download and installation process of the MikroTik RouterOS is described in the following diagram:



1. Download the basic installation archive file.

Depending on the desired media to be used for installing the MikroTik RouterOS please chose one of the following archive types for downloading:

- **ISO image** of the installation CD, if you have a CD writer for creating CDs. The ISO image is in the MTcdimage_v2-6-x_dd-mmm-yyyy.zip archive file containing a bootable CD image. The CD will be used for booting up the dedicated PC and installing the MikroTik RouterOS on its hard-drive or flash-drive.
- **MikroTik Disk Maker**, if you want to create 3.5" installation floppies. The Disk Maker is a self-extracting archive DiskMaker_v2-6-x_dd-mmm-yyyy.exe file, which should be run on your Win95/98/NT4/2K/XP workstation to create the installation floppies. The installation floppies will be used for booting up the dedicated PC and installing the MikroTik RouterOS on its hard-drive or flash-drive.
- **MikroTik Disk Maker in a set of smaller files**, if you have problems downloading one large file.
- **Netinstall**, if you want to install RouterOS over a LAN with one floppy boot disk

Note! The installation from CD or network requires Full (paid) License. If you intend to obtain the Free Demo License, you should use the floppy installation media.

2. Create the installation media

Use the appropriate installation archive to create the Installation CD or floppies.

- For the CD, write the ISO image onto a blank CD.
- For the floppies, run the Disk Maker on your Windows workstation to create the installation floppies. Follow the instructions and insert the floppies in your FDD as requested, label them as Disk 1,2,3, etc.

3. Install the MikroTik RouterOS software.

Your dedicated PC router hardware should have:

- An advanced 4th generation (core frequency 100MHz or more), 5th generation (Intel Pentium, Cyrix 6X86, AMD K5 or comparable) or newer Intel IA-32 (i386) compatible **motherboard and processor** (dual processors are not supported);
- from 32MB to 1GB **RAM** (from 48MB suggested);
- 30MB or more **PRIMARY MASTER IDE HDD or IDE flashdrive**. Note: The hard disk will be entirely reformatted during the installation and all data on it will be lost!
- A **network adapter** (NE2000 compatible PCI or ISA Ethernet card, or any other supported NIC, see specifications of supported interfaces on our web page);

Note that you can move the hard drive with MikroTik RouterOS installed to a new hardware without losing a license, but you cannot move the RouterOS to a different hard drive without purchasing another license (except hardware failure situations). For additional information write to key-support@mikrotik.com

For installation purposes (and only for that time) you should also have:

- A **SECONDARY MASTER CD drive** set as **primary boot** device, if you want to use the created CD for installing the MikroTik RouterOS onto the primary master HDD;
- A **3.5" FDD** set as primary boot device, if you want to use the created set of floppies for installing the MikroTik RouterOS;
- A **monitor and keyboard** for installation and initial setup of the MikroTik Router. The monitor and keyboard do not need to be connected to the router after it is set up for connecting to it over the network.

Boot up your dedicated PC router from the Installation Media you created and follow the instructions on the console screen while the HDD is reformatted and MikroTik RouterOS installed on it.


After successful installation please remove the installation media from your CD or floppy disk drive and hit 'Enter' to reboot the router. While the router will be starting up for the first time you will be given a **Software ID** for your installation and asked to supply a valid software license key (**Software Key**) for it. Write down the Software ID. You will need it to obtain the Software License through the MikroTik Account Server.

If you need extra time to obtain the Software License Key, you may want to power off the router. Type **shutdown** in the Software key prompt and power the router off when the router is halted.

Obtaining the Software License

The MikroTik RouterOS Software licensing process is described in the following diagram:

Setting up MikroTik RouterOS




After installing the router and starting it up for the first time you will be given a Software ID.

1. Write down the Software ID reported by the RouterOS.
2. If you have an account with MikroTik, follow to the next step.
If you do not have an account at www.mikrotik.com, just press the 'New' button on the upper right-hand corner of the MikroTik's web page to create your account.



You will be presented with the Account Sign-Up Form where you chose your account name and fill in the required information.

3. To obtain the Software License Key, log on to your account at www.mikrotik.com entering your account name and password (upper right-hand corner on this webpage), for example:



4. After logging on to the Account Server select "Free Demo License" or "Order Software License" in the Account Menu.

Note! The CD or Netinstall installation cannot be 'unlocked' with the Free Demo Key. Use the Floppy installation, or, purchase the License Key.

5. The Software Key will be sent to the email address, which has been specified in your account setup.
6. Read your email and enter the Software Key at the router's console, for example:

```
Software ID: 5T4V-IUT
Software key: 4N7X-UZ8-6SP
```

Setting up MikroTik RouterOS

Instead of entering the license key you can enter **shutdown** to shut down the router and enter the license key later, or enter **display** to read the License Agreement, or **help** to see a help message.

After entering the correct Software License Key you will be presented with the MikroTik Router's login prompt.

Logging into the MikroTik Router

When logging into the router via terminal console, you will be presented with the MikroTik RouterOS login prompt. Use 'admin' and no password (hit 'Enter') for logging on to the router for the first time, for example:

```
MikroTik v2.6
Login: admin
Password:
```

The password can be changed with the `/password` command.

Adding Software Packages

The basic installation comes with only the "system" package and few other packages. This includes basic IP routing and router administration. To have additional features such as IP Telephony, OSPF, wireless, and so on, you will need to download additional software packages.

The additional software packages should have **the same version** as the system package. If not, the package wont be installed. Please consult the MikroTik RouterOS Software Package Installation and Upgrading Manual for more detailed information about installing additional software packages.

Software Licensing Issues

If you want to upgrade to a 'paid' version of your MikroTik RouterOS installation, please purchase the new Software License KEY for the Software ID you used when getting the 'free' demo license. Similarly, if additional license is required to enable the functionality of a software package, the license should be obtained for the Software ID of your system. The new key should be entered using the `/system license set key` command, and the router should be rebooted afterwards:

```
[admin@MikroTik] ip firewall src-nat> /system license print
      software-id: "SB5T-R8T"
              key: "3YIY-ZV8-DH2"
  upgradable-unit1: may/01/2003
[admin@MikroTik] system license> feature print
Flags: X - disabled
#   FEATURE
0 X AP
1 X synchronous
2 X radiolan
3 X wireless-2.4GHz
4   licensed
[admin@MikroTik] system license> set key=D45G-IJ6-QM3
[admin@MikroTik] system license> /system reboot
Reboot, yes? [y/N]: y
system will reboot shortly
```

If there is no appropriate license, the appropriate interfaces wont show up under the interface list, even though the packages can be installed on the MikroTik RouterOS and corresponding drivers loaded.

Navigating the Terminal Console

After logging into the router you will be presented with the MikroTik RouterOS Welcome Screen and command prompt, for example:

```
MMM      MMM      KKK      TTTTTTTTTTTT      KKK
MMMM     MMMM     KKK      TTTTTTTTTTTT      KKK
MMM MMMM MMM III KKK KKK RRRRRR      OOOOOO      TTT      III KKK KKK
MMM MM  MMM III KKKKK RRR RRR OOO OOO TTT      III KKKKK
MMM      MMM III KKK KKK RRRRRR      OOO OOO TTT      III KKK KKK
MMM      MMM III KKK KKK RRR RRR OOOOOO      TTT      III KKK KKK
```

```
MikroTik RouterOS v2.6 (c) 1999-2002      http://www.mikrotik.com/
```

```
Terminal xterm detected, using multiline mode
[admin@MikroTik] >
```

The command prompt shows the identity name of the router and the current menu level, for example:

```
[MikroTik] >          Base level menu
[MikroTik] interface> Interface configuration
[MikroTik] ip address> IP Address management
```

The list of available commands at any menu level can be obtained by entering the question mark '?', for example:

```
[admin@MikroTik] > ?

driver  Driver management
file    Local router file storage.
import  Run exported configuration script
interface Interface configuration
log     System logs
password Change password
ping    Send ICMP Echo packets
port    Serial ports
quit    Quit console
redo    Redo previously undone action
setup   Do basic setup of system
undo    Undo previous action
user    User management
ppp
snmp    snmp settings
isdn-channels ISDN channel status info
ip
queue   Bandwidth management
system  System information and utilities
tool
routing
export
```

```
[admin@MikroTik] > ip ?

accounting Traffic accounting
address   Address management
arp       ARP entries management
dns       DNS settings
firewall  Firewall management
neighbour neighbours
packing   Packet packing settings
pool      IP address pools
```

Navigating the Terminal Console

```
route      Route management
service
policy-routing
dhcp-client DHCP client settings
dhcp-server DHCP server settings
dns-cache
ipsec
web-proxy  HTTP proxy
telephony  IP Telephony interface
export
[admin@MikroTik] > ip
```

The list of available commands and menus has short descriptions next to the items. You can move to the desired menu level by typing its name and hitting the [Enter] key, for example:

```
[admin@MikroTik]>                               Base level menu
[admin@MikroTik]> driver                          Enter 'driver' to move to the driver level
                                                    menu
[admin@MikroTik] driver> /                        Enter '/' to move to the base level menu
                                                    from any level
[admin@MikroTik]> interface                       Enter 'interface' to move to the interface
                                                    level menu
[admin@MikroTik] interface> /ip                  Enter '/ip' to move to the IP level menu
                                                    from any level
[admin@MikroTik] ip>
```

A command or an argument does not need to be completed, if it is not ambiguous. For example, instead of typing 'interface' you can type just 'in' or 'int'. To complete a command use the [Tab] key.

The commands may be invoked from the menu level, where they are located, by typing its name. If the command is in a different menu level than the current one, then the command should be invoked using its full or relative path, for example:

```
[admin@MikroTik] ip route> print                 Prints the routing table
[admin@MikroTik] ip route> .. address print      Prints the IP address table
[admin@MikroTik] ip route> /ip address print     Prints the IP address table
```

The commands may have arguments. The arguments have their names and values. Some arguments, that are required, may have no name. Below is a summary on executing the commands and moving between the menu levels:

Command	Action
command [Enter]	Execute the command
[?]	Show the list of all available commands
command [?]	Display help on the command and the list of arguments
command argument [?]	Display help on the command's argument
[Tab]	Complete the command/word. If the input is ambiguous, a second [Tab] gives possible options
/	Move up to the base level
/command	Execute the base level command
..	Move up one level
""	Enter an empty string
"word1 word2"	Enter 2 words that contain a space

You can abbreviate names of levels, commands and arguments.

For the IP address configuration, instead of using the 'address' and 'netmask' arguments, in most cases you can specify the address together with the number of bits in the network mask, i.e., there is no need to specify the 'netmask' separately. Thus, the following two entries would be equivalent:

Navigating the Terminal Console

```
/ip address add address 10.0.0.1/24 interface ether1  
/ip address add address 10.0.0.1 netmask 255.255.255.0 interface ether1
```

However, if the netmask argument is not specified, you **must** specify the size of the network mask in the address argument, even if it is the 32-bit subnet, i.e., use 10.0.0.1/32 for address 10.0.0.1 and netmask 255.255.255.255

Accessing the Router Remotely Using Web Browser and WinBox Console

The MikroTik router can be accessed remotely using

- the **telnet** protocol, for example, using the telnet client of your Windows or Unix workstation. Working with the telnet console is the same as working with the monitor and keyboard attached to the router locally.
- the **ftp** for uploading the software upgrade packages or retrieving the exported configuration files.
- the **http** and **WinBox Console**, for example, using the web browser of your workstation.

Overview

The Winbox Console is used for accessing the MikroTik Router configuration and management features using graphical user interface.


All Winbox interface functions are as close as possible to Console functions: all Winbox functions are exactly in the same place in Terminal Console and vice versa (except functions that are not implemented in Winbox). That is why there are no Winbox sections in the manual.

The Winbox Console plugin loader, the winbox.exe program, can be retrieved from the MikroTik router, the URL is http://router_address/winbox/winbox.exe Use any web browser on Windows 95/98/ME/NT4.0/2000/XP to retrieve the router's web page with the mentioned link.

The winbox plugins are cached on the local disk for each MikroTik RouterOS version. The plugins are not downloaded, if they are in the cache, and the router has not been upgraded since the last time it has been accessed.

Starting the Winbox Console

When connecting to the MikroTik router via http (TCP port 80), the router's Welcome Page is displayed in the web browser, for example:



By clicking on the Winbox Console link you can start the winbox.exe download. Choose the option "Run this program from its current location" and click "OK":

Accessing the Router Remotely Using Web Browser and WinBox Console



Accept the security warning, if any:




Alternatively, you can save the winbox.exe program to your disk and run it from there.

The winbox.exe program opens the Winbox login window. Login to the router by specifying the IP address, user name, and password, for example:




Watch the download process of Winbox plugins:

Accessing the Router Remotely Using Web Browser and WinBox Console



The Winbox console is opened after the plugins have been downloaded:



The Winbox Console uses TCP port 3987. After logging on to the router you can work with the MikroTik router's configuration through the Winbox console and perform the same tasks as using the regular console.

Overview of Common Functions

You can use the menu bar to navigate through the router's configuration menus, open configuration windows. By double clicking on some list items in the windows you can open configuration windows for the specific items, and so on.

There are some hints for using the Winbox Console:

- To open the required window, simply click on the corresponding menu item.
- To add a new entry you should click on the **+** icon in the corresponding window.
- To remove an existing entry click on the **-** icon.
- To enable an item, click on the **✓** icon.
- To disable an item, click on the **✗** icon.
- To make or edit a comment for a selected item, click on the **📝** icon.
- To refresh the window, click on the **🔄** icon.

Accessing the Router Remotely Using Web Browser and WinBox Console

- To undo an action, click on the  icon above the main menu.
- To redo an action, click on the  icon above the main menu.
- To logout from the Winbox Console, click on the  icon.

Troubleshooting for Winbox Console

- *Cannot get the MikroTik RouterOS Winbox to start. The "Missing RouterOS Winbox plugins" message is displayed.*

You can try to clear the winbox cache or wipe out the cache folder, and then reload the plugins:

- ◆ To clear the winbox plugin cache on your computer, choose the Clear Cache option in the Winbox system menu of the login window:



- ◆ To wipe out the winbox plugin cache on your computer, find the cache file location using the registry
Key="HKEY_CURRENT_USER\Software\Microsoft\Windows\CurrentVersion\Explorer\ShellFolders\AppData"
For example, for the user 'Administrator' on W2K, the Winbox folder is under
C:\Documents and Settings\Administrator\Application Data\Mikrotik
On W95/98 the Winbox folder is under C:\Windows\Application Data\Mikrotik
- *I still cannot open the Winbox Console*
The Winbox Console uses TCP port 3987. Make sure you have access to it through the firewall.

Configuring Basic Functions

Working with Interfaces

Before configuring the IP addresses and routes please check the **/interface** menu to see the list of available interfaces. If you have PCI Ethernet cards installed in the router, it is most likely that the device drivers have been loaded for them automatically, and the relevant interfaces appear on the **/interface print** list, for example:

```
[admin@MikroTik] interface> print
Flags: X - disabled, D - dynamic, R - running
#   NAME                TYPE                MTU
0   R ether1             ether                1500
1   R ether2             ether                1500
2   R ether3             ether                1500
3   R ether4             ether                1500
4   R ether5             ether                1500
5   R sync1              sync                 1500
6   R pc1                 pc                   1500
7   R ether6             ether                1500
8   R prism1             prism                1500
[admin@MikroTik] interface>
```

The device drivers for NE2000 compatible ISA cards need to be loaded using the **add** command under the **/drivers** menu. For example, to load the driver for a card with IO address 0x280 and IRQ 5, it is enough to issue the command:

```
[admin@MikroTik] driver> add name=ne2k-isa io=0x280
[admin@MikroTik] driver> print
Flags: I - invalid, D - dynamic
#   DRIVER                IRQ IO          MEMORY   ISDN-PROTOCOL
0   D RealTek 8139
1   D Intel EtherExpressPro
2   D PCI NE2000
3   ISA NE2000            280
4   Moxa C101 Synchronous          C8000
[admin@MikroTik] driver>
```

The interfaces need to be enabled, if you want to use them for communications. Use the **/interface enable name** command to enable the interface with a given name, for example:

```
[admin@MikroTik] interface> print
Flags: X - disabled, D - dynamic, R - running
#   NAME                TYPE                MTU
0   X ether1             ether                1500
0   X ether2             ether                1500
[admin@MikroTik] interface> enable 0
[admin@MikroTik] interface> enable ether2
[admin@MikroTik] interface> print
Flags: X - disabled, D - dynamic, R - running
#   NAME                MTU   TYPE
0   R ether1             1500  ether
0   R ether2             1500  ether
[admin@MikroTik] interface>
```

You can use the number or the name of the interface in the **enable** command.

The interface name can be changed to a more descriptive one by using the **/interface set** command:

```
[admin@MikroTik] interface> set 0 name=Public
```

Configuring Basic Functions


```
[admin@MikroTik] interface> set 1 name=Local
[admin@MikroTik] interface> print
Flags: X - disabled, D - dynamic, R - running
#   NAME           MTU   TYPE
0   R Public       ether 1500
0   R Local        ether 1500
[admin@MikroTik] interface>
```

Use of the 'setup' Command

The initial setup of the router can be done by using the **/setup** command which enables an interface, assigns an address/netmask to it, and configures the default route. If you do not use the **setup** command, or need to modify/add the settings for addresses and routes, please follow the steps described below.

Adding Addresses

Assume you need to configure the MikroTik router for the following network setup:



Please note that the addresses assigned to different interfaces of the router should belong to different networks. In the current example we use two networks:

- The local LAN with network address 192.168.0.0 and 24-bit netmask 255.255.255.0 The router's address is 192.168.0.254 in this network.
- The ISP's network with address 10.0.0.0 and 24-bit netmask 255.255.255.0 The router's address is 10.0.0.217 in this network.

The addresses can be added and viewed using the following commands:

```
[admin@MikroTik] ip address> add address 192.168.0.254/24 interface Local
[admin@MikroTik] ip address> add address 10.0.0.217/24 interface Public
[admin@MikroTik] ip address> print
Flags: X - disabled, I - invalid, D - dynamic
#   ADDRESS           NETWORK           BROADCAST         INTERFACE
0   10.0.0.217/24     10.0.0.217       10.0.0.255       Public
1   192.168.0.254/24 192.168.0.0     192.168.0.255   Local
[admin@MikroTik] ip address>
```

Configuring Basic Functions

Here, the network mask has been specified in the value of the address argument. Alternatively, the argument 'netmask' could have been used with the value '255.255.255.0'. The network and broadcast addresses were not specified in the input since they could be calculated automatically.

Configuring the Default Route

You can see two dynamic (D) and connected (C) routes, which have been added automatically when the addresses were added:

```
[admin@MikroTik] ip route> print
Flags: X - disabled, I - invalid, D - dynamic, J - rejected,
C - connect, S - static, R - rip, O - ospf, B - bgp
#   DST-ADDRESS      G GATEWAY          DISTANCE INTERFACE
0 DC 192.168.0.0/24  r 0.0.0.0         0         Local
1 DC 10.0.0.0/24    r 0.0.0.0         0         Public

[admin@MikroTik] ip route> print detail
Flags: X - disabled, I - invalid, D - dynamic, J - rejected,
C - connect, S - static, R - rip, O - ospf, B - bgp
0 DC dst-address=192.168.0.0/24 preferred-source=192.168.0.254
   gateway=0.0.0.0 gateway-state=reachable distance=0 interface=Local

1 DC dst-address=10.0.0.0/24 preferred-source=10.0.0.217 gateway=0.0.0.0
   gateway-state=reachable distance=0 interface=Public

[admin@MikroTik] ip route>
```

These routes show, that IP packets with destination to 10.0.0.0/24 would be sent through the interface Public, whereas IP packets with destination to 192.168.0.0/24 would be sent through the interface Local. However, you need to specify where the router should forward packets, which have destination other than networks connected directly to the router. This is done by adding the **default route** (destination 0.0.0.0, netmask 0.0.0.0). In this case it is the ISP's gateway 10.0.0.1, which can be reached through the interface Public:

```
[admin@MikroTik] ip route> add gateway=10.0.0.1
[admin@MikroTik] ip route> print
Flags: X - disabled, I - invalid, D - dynamic, J - rejected,
C - connect, S - static, R - rip, O - ospf, B - bgp
#   DST-ADDRESS      G GATEWAY          DISTANCE INTERFACE
0 S 0.0.0.0/0       r 10.0.0.1        1         Public
1 DC 192.168.0.0/24  r 0.0.0.0         0         Local
2 DC 10.0.0.0/24    r 0.0.0.0         0         Public

[admin@MikroTik] ip route>
```

Here, the default route is listed under #0. As we see, the gateway 10.0.0.1 can be reached through the interface 'Public'. If the gateway was specified incorrectly, the value for the argument 'interface' would be unknown. Note, that you cannot add two routes to the same destination, i.e., destination-address/netmask! It applies to the default routes as well. Instead, you can enter multiple gateways for one destination. For more information on IP routes, please read the relevant topic in the Manual.

If you have added an unwanted static route accidentally, use the **remove** command to delete the unneeded one. **Do not remove the dynamic (D) routes!** They are added automatically and should not be deleted 'by hand'. If you happen to, then reboot the router, the route will show up again.

Testing the Network Connectivity

From now on, the **/ping** command can be used to test the network connectivity on both interfaces. You can reach any host on both connected networks from the router:

Configuring Basic Functions

```
[admin@MikroTik] ip route> /ping 10.0.0.4
10.0.0.4 64 byte pong: ttl=255 time=7 ms
10.0.0.4 64 byte pong: ttl=255 time=5 ms
10.0.0.4 64 byte pong: ttl=255 time=5 ms
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max = 5/5.6/7 ms
[admin@MikroTik] ip route>
[admin@MikroTik] ip route> /ping 192.168.0.1
192.168.0.1 64 byte pong: ttl=255 time
```

The workstation and the laptop can reach (ping) the router at its local address 192.168.0.254, If the router's address 192.168.0.254 is specified as the default gateway in the TCP/IP configuration of both the workstation and the laptop, then you should be able to ping the router:

```
C:\>ping 192.168.0.254
Reply from 192.168.0.254: bytes=32 time=10ms TTL=253
Reply from 192.168.0.254: bytes=32 timeping 10.0.0.217
Reply from 10.0.0.217: bytes=32 time=10ms TTL=253
Reply from 10.0.0.217: bytes=32 timeping 10.0.0.4
Request timed out.
Request timed out.
Request timed out.

C:\>
```

You cannot access anything beyond the router (network 10.0.0.0/24 and the Internet), unless you do the following:

- Use source network address translation (masquerading) on the MikroTik router to 'hide' your private LAN 192.168.0.0/24 (see the information below), or
- Add a static route on the ISP's gateway 10.0.0.1, which specifies the host 10.0.0.217 as the gateway to network 192.168.0.0/24. Then all hosts on the ISP's network, including the server, will be able to communicate with the hosts on the LAN.

To set up routing, it is required that you have some knowledge of configuring TCP/IP networks. There is a comprehensive list of IP resources compiled by Uri Raz at http://www.private.org.il/tcpip_rl.html We strongly recommend that you obtain more knowledge, if you have difficulties configuring your network setups.

Next will be discussed situation with 'hiding' the private LAN 192.168.0.0/24 'behind' one address 10.0.0.217 given to you by the ISP.

Application Examples

Application Example with Masquerading

If you want to 'hide' the private LAN 192.168.0.0/24 'behind' one address 10.0.0.217 given to you by the ISP, you should use the source network address translation (masquerading) feature of the MikroTik router. Masquerading is useful, if you want to access the ISP's network and the Internet appearing as all requests coming from the host 10.0.0.217 of the ISP's network. The masquerading will change the source IP address and port of the packets originated from the network 192.168.0.0/24 to the address 10.0.0.217 of the router when the packet is routed through it.

Masquerading conserves the number of global IP addresses required and it lets the whole network use a single IP address in its communication with the world.

To use masquerading, a source NAT rule with action 'masquerade' should be added to the firewall configuration:

```
[admin@MikroTik] ip firewall src-nat> add action=masquerade out-interface=Public
[admin@MikroTik] ip firewall src-nat> print
Flags: X - disabled, I - invalid
 0  src-address=0.0.0.0/0:0-65535 dst-address=0.0.0.0/0:0-65535
    out-interface=Public protocol=all icmp-options=any:any flow=""
    limit-count=0 limit-burst=0 limit-time=0s action=masquerade
    to-src-address=0.0.0.0 to-src-port=0-65535 bytes=0 packets=0

[admin@MikroTik] ip firewall src-nat>
```

Please consult the **Firewall Manual** for more information on masquerading.

Application Example with Bandwidth Management

Mikrotik RouterOS V2.6 offers extensive queue management. For information on queue management, please refer to the relevant manual.

Assume you want to limit the bandwidth to 128kbps on downloads and 64kbps on uploads for all hosts on the LAN. Bandwidth limitation is done by applying queues for outgoing interfaces regarding the traffic flow. It is enough to add two queues at the MikroTik router:

```
[admin@MikroTik] queue simple> add interface Local limit-at 128000
[admin@MikroTik] queue simple> add interface Public limit-at 64000
[admin@MikroTik] queue simple> print
Flags: X - disabled, I - invalid
 0  name="" src-address=0.0.0.0/0 dst-address=0.0.0.0/0 interface=Local
    limit-at=128000 queue=default priority=8 bounded=yes

 1  name="" src-address=0.0.0.0/0 dst-address=0.0.0.0/24 interface=Public
    limit-at=64000 queue=default priority=8 bounded=yes


[admin@MikroTik] queue simple>
```

Leave all other parameters as set by default. The limit is approximately 128kbps going to the LAN and 64kbps leaving the client's LAN. Please note, that the queues have been added for the outgoing interfaces regarding the traffic flow.

Please consult the **Queues Manual** for more information on bandwidth management and queuing.

Application Example with NAT

Assume we have moved the server in our previous examples from the public network to our local one:



The server's address now is 192.168.0.4, and we are running a web server on it that listens to the TCP port 80. We want to make it accessible from the Internet at address:port 10.0.0.217:80. This can be done by means of Static Network Address translation (NAT) at the MikroTik Router. The Public address:port 10.0.0.217:80 will be translated to the Local address:port 192.168.0.4:80. One destination NAT rule is required for translating the destination address and port:

```
[admin@MikroTik] ip firewall dst-nat> add action=nat protocol=tcp \
dst-address=10.0.0.217/32:80 to-dst-address=192.168.0.4
[admin@MikroTik] ip firewall dst-nat> print
Flags: X - disabled, I - invalid
 0  src-address=0.0.0.0/0:0-65535 in-interface=all
    dst-address=10.0.0.217/32:80 protocol=tcp icmp-options=any:any flow=""
    src-mac-address=00:00:00:00:00:00 limit-count=0 limit-burst=0
    limit-time=0s action=nat to-dst-address=192.168.0.4 to-dst-port=0-65535
```

```
[admin@MikroTik] ip firewall dst-nat>
```

Please consult the **Firewall Manual** for more information on NAT.

' Copyright 1999–2002, MikroTik